

BRAKE TREADLE




Figure BR

BRAKE TREADLE

KEY NO.	PART NAME	QTY.	KEY NO.	PART NAME	QTY.
BR-1	Brake Pad	4	BR-17	Treadle Connecting Link	1
BR-2	Pressure Bar	2	BR-18	Brake Lever Pivot Pin	1
BR-3	Brake Lever	2	BR-19	Ratchet Pawl	1
BR-4	Brake Lever Pivot Bearing	4	BR-20	Ratchet Lever	1
BR-5	Lever Roller Pin	2	BR-21	Ratchet Lever Return Spring	1
BR-6	Spring	2	BR-22	Ratchet Lever Pin	1
BR-7	Pressure Bar Retaining Screw Spacer	4	BR-23	Ratchet Pivot Pin Collar	1
BR-8	Wedge Follower Roller	2	BR-24	Treadle Return Spring Rod	1
BR-9	Brake Lever Pivot Pin	2	BR-25	Treadle Return Spring	1
BR-10	Caliper Brake Housing	1	BR-26	Brake Lever	1
BR-11	Treadle Mounting Plate	1	BR-27	Treadle Link	1
BR-12	Brake Lever Mounting Bracket	1	BR-28	Treadle Pivot Pin Collar	1
BR-13	Brake Lever Pivot Bushing	1	BR-29	Treadle Pivot Bushing	1
BR-14	Actuating Wedge	2	BR-30	Treadle Pivot Pin	1
BR-15	Brake Treadle Connecting Pin	4	BR-31	Treadle	1
BR-16	Ratchet Plate	1			