

DISCHARGE EJECTOR
45, 56, 68 HEADERS




Figure DF

DISCHARGE EJECTOR
45, 56, 68 HEADERS

KEY NO.	PART NAME	QTY.
DF-1	Lower Connection End	1
DF-2	Front Cartridge	1
DF-3	Spring Rod Pin	1
DF-4	Roller Lever	1
DF-5	Roller Lever Rear Bearing	1
DF-6	Spring Rod Pin Bearing	1
DF-7	Roller Washers	2
DF-8	Cam Roller	1
DF-9	Roller Pin	1
DF-10	Spring Rod	1
DF-11	Blade to Lever Stud	1
DF-12	Blade Clamp	1
DF-13	Blade (Short Blanks)	1
DF-15	Roller Lever Spacer	1
DF-16	Roller Lever Front Bearing	1
DF-17	Drive Lever Key	1
DF-18	Spring	1
DF-19	Blade (Long Blanks)	1
DF-20	Blade Spacer	1
DF-21	Lever	1
DF-22	Roller Lever Washer	1
DF-23	Lever Pivot Block	1
DF-24	Connection Pin - Lower	1
DF-25	Lever Bearing	1
DF-26	Rear Cartridge	1
DF-27	Spring Bracket	1
DF-28	Spring Rod Bush	1
DF-29	Spring Rod Adjusting Screw	1
DF-30	Upper Connection End	1
DF-31	Connection Rod Bearing	2
DF-32	Drive Lever	1
DF-33	Connection Rod	1
DF-34	Connection Pin - Upper	1