

HEADING SLIDE LINERS*




Figure 1

HEADING SLIDE LINERS*

KEY NO.	PART NAME	QTY
1-1	LH Rear Heading Slide Cap	1
1-2	Liner for LH Rear Heading Slide	1
1-3	LH Liner under Rear of Heading Slide	1
1-4	Left Side, Rear Heading Slide Liner	1
1-5	RH Rear Heading Slide Cap	1
1-6	Liner for RH Rear Heading Slide Cap	1
1-7	Right Side, Rear Heading Slide Liner	1
1-8	RH Liner under Rear of Heading Slide	1
1-9	LH Front Heading Slide Cap	1
1-10	Liner on LH Front Heading Slide Cap	1
1-11	LH Liner under Front of Heading Slide	1
1-12	RH Front Heading Slide Cap	1
1-13	Liner on RH Front Heading Slide Cap	1
1-14	LH Front Heading Slide Side Liner	1
1-15	Base Rest for Face Plate and Die Block	1

* See Figure 2 for R. H. Front Liners